



ASSEMBLY AND OPERATING INSTRUCTION MANUAL



**3 GALLON (11L)
PUMP SPRAYER**
Product# 708908



**2 GALLON (8L)
PUMP SPRAYER**
Product# 708906




**1 GALLON (4L)
PUMP SPRAYER**
Product# 708904


Please read this manual for instructions and precautions before using this product. Keep this manual and the receipt in a safe place for future reference!

Part #	Description	Quantity
A	Tank & Pump Assembly	1
B	Sprayer Wand	1

A



B



Remove all contents from the packaging. If parts are missing do not attempt to use until all parts are obtained.

IMPORTANT SAFETY INFORMATION

WARNING - Read all instructions thoroughly. If directions are not fully understood or a problem occurs please contact your local dealer.

1. Use ANSI-approved safety goggles and other safety gear.
2. Always point nozzle in a safe direction.
3. Always spray in the same direction as the wind.
4. Do not overfill.
5. Always release pressure after each use and before storage.
6. Always follow manufacturer's instructions when mixing, storing and disposing of waste. Open dumping is prohibited.
7. Do not pull or carry sprayer by the spray handle or hose.
8. Clean sprayer to protect it from corrosion and possible chemical reactions between the residue chemicals and next chemicals if they are of different nature.
9. Do not use with flammable or corrosive solution.
10. Keep out of reach of children.


ASSEMBLY INSTRUCTIONS

ATTACHING THE WAND

(Figure 1)

1. Rotate the wand nut (A) counter clockwise to loosen.
2. Insert the wand shaft (B) through the nut and into the Sprayer Handle (C).
3. Rotate wand nut clockwise to secure wand.

Figure 1



OPERATION


TO FILL THE TANK

(Figure 2)

WARNING: Before opening tank release pressure using the pressure release valve (A).

1. Use the pump handle (B) when in the locked position and turn counterclockwise to loosen. Remove the pump.
2. Fill tank according to the manufacturer's instruction for the chemical being used. DO NOT exceed the max fill line.
3. Replace the pump and rotate clockwise to tighten.


Figure 2



PRESSURIZING THE TANK

(Figure 3)


1. To release the pump, rotate handle (A) to the unlocked position and lift up.
2. Pump the handle up and down until tank becomes pressurized.
3. Lower pump handle and rotate handle to the locked position.



SPRAYING

(Figure 4)

1. To start spraying press the lever (A) on the spray handle.
2. For continuous spray operation slide the lever forward to “lock-on position.” The sprayer will be in continuous operation. Pull back on the lever to disengage continuous spray.




ADJUSTING NOZZLE

(Figure 5)

1. Rotate nozzle (A) clockwise for jet spray pattern.
2. Rotate nozzle (A) counter-clockwise for fine mist.


Do not adjust nozzle when continuous spraying lock is on. Be careful not to fully unscrew nozzle.



PRESSURE RELEASE

(Figure 6)

1. To release pressure, lift the top of the pressure release valve (A).



MAINTENANCE AND STORAGE

1. Be sure to empty tank (Follow proper manufacture disposal instructions). Clean after each use with a mild soap and water solution. Run water through the nozzle wand, hose, and tank to remove traces of chemicals.
2. Rinse both the inside and outside of the tank thoroughly with clean water. Rinse nozzle, wand and hose as well.
3. Allow parts to dry prior to storage. Store in a clean dry area such as a garage or shed. Keep out of reach of children.
4. Occasionally lubricate the pump O-ring with petroleum jelly.

LIQUID VOLUME CONVERSION CHART

OUNCES	CUPS	PINTS	QUARTS	GALLONS	LITERS_(APX)
4 OZ	1/2 C	1/4 PT	1/8 QT	1/32 GAL	1/8 L
8 OZ	1 C	1/2 PT	1/4 QT	1/16 GAL	1/4 L
16 OZ	2 C	1 PT	1/2 QT	1/8 GAL	1/2 L
32 OZ	4 C	2 PT	1 QT	1/4 GAL	1 L
64 OZ	8 C	4 PT	2 QT	1/2 GAL	2 L
128 OZ	16 C	8 PT	4 QT	1 GAL	4 L
256 OZ	32 C	16 PT	8 QT	2 GAL	8 L
384 OZ	48 C	24 PT	12 QT	3 GAL	11 L
512 OZ	64 C	32 PT	16 QT	4 GAL	16 L
640 OZ	80 C	40 PT	20 QT	5 GAL	20 L

RAINMAKER™ PRODUCTS

In addition to the Pressure Pump Sprayers, Rainmaker™ multi-purpose sprayers are available in a variety of other sizes for home and garden use:

32 oz HAND SPRAYER

PRODUCT # 708502



64 oz HAND SPRAYER

PRODUCT # 708500



4 GALLON BACKPACK PUMP SPRAYER

PRODUCT # 708900



5 GALLON BATTERY POWERED ELECTRIC SPRAYER

PRODUCT # 708902



Scan to learn more about Rainmaker™ multi-purpose sprayers for home and garden use or visit:

www.RainmakerSprayers.com